



If switch at Stop input is closed, all 4 relays are switched off. When opened again, they return to their state preset in configurations.