

# INFINITY MATRIX 360R ARGB

MANUAL

[www.Antec.com](http://www.Antec.com)


All rights reserved. Specifications are subject to change without prior notice. Actual products and accessories may differ from illustrations. Omissions and printing errors excepted. Content of delivery might differ in different countries or areas. Some trademarks may be claimed as the property of others.

V2.2

©1986 – 2025 Antec Inc. All rights reserved.

## 1 CONTENTS


### 360MM FAN




### FAN SCREW



### RADIATOR SCREW




## 2 FAN INTRODUCTION




AIR-IN

AIR-OUT

### 3 FAN DIMENSIONS




SIDE




### 4 FAN INSTALLATION

- Install on the chassis with less screws



### 5 FAN CONNECTION

- Connect to the motherboard



\*Supports motherboards or controllers with ARGB control for 56 LEDs.